

# EMX-B75

Intel® Core™ i7/ i5/ i3/ Pentium®/ Celeron® Mini ITX  
Motherboard with Intel® B75 Chipset

## Quick Installation Guide

4<sup>th</sup> Ed – 13 September 2013

### FCC Statement



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

### Notice

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

### Copyright Notice

Copyright © 2013 Avalue Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

### A Message to the customer

#### *Avalue Customer Services*

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

## **EMX-B75 Quick Installation Guide**

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

### ***Technical Support***

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at:

<http://www.avalue.com.tw/>

### **Headquarters and Branch**

#### **Avalue Technology Inc.**

7F, 228, Lian-cheng Road, Zhonghe Dist., New Taipei City 235, Taiwan

Tel: +886-2-8226-2345

Fax: +886-2-8226-2777

Information: [sales@avalue.com.tw](mailto:sales@avalue.com.tw)

Service: [service@avalue.com.tw](mailto:service@avalue.com.tw)

#### **Avalue USA**

##### **Avalue Technology Inc.**

9 Timber Lane, Marlboro, NJ 07746-1443

Tel: (732) 414-6500

Fax: (732) 414-6501

Information: [sales@avalue-usa.com](mailto:sales@avalue-usa.com)

Service: [support@avalue-usa.com](mailto:support@avalue-usa.com)

#### **Avalue Europe**

##### **Avalue Europe A/S**

Moelledalen 22C, 3140

Aalsgaarde, Denmark

Tel: +45-7025-0310

Fax: +45-4975-5026

Information: [sales.europe@avalue.com.tw](mailto:sales.europe@avalue.com.tw)

Service: [service.europe@avalue.com.tw](mailto:service.europe@avalue.com.tw)

#### **BCM Advanced Research**

##### **BCM Advanced Research an Avalue Company**

7 Marconi, Irvine, CA92618

Tel: +1-949-470-1888

Fax: +1-949-470-0971

Information: [BCMSales@bcmcom.com](mailto:BCMSales@bcmcom.com)

Web: [www.bcmcom.com](http://www.bcmcom.com)

#### **Avalue China**

##### **Avalue Technology Inc.**

Room 805, Building 9, No.99 Tianzhou Rd.,

Caohejing Development Area,

Xuhui District, Shanghai

Tel: +86-21-5169-3609

Fax: +86-21-5445-3266

Information: [sales.china@avalue.com.cn](mailto:sales.china@avalue.com.cn)

Service: [service@avalue.com.tw](mailto:service@avalue.com.tw)

# 1. Getting Started

## 1.1 Safety Precautions

### Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

### Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

**Always note** that improper disassembling action could cause damage to the motherboard. We suggest not removing the heatsink without correct instructions in any circumstance. If you really have to do this, please contact us for further support.

## 1.2 Packing List


Before you begin installing your single board, please make sure that the following materials have been shipped:

- Quick Installation Guide X 1
- Driver/Utility CD X 1
- Serial ATA Signal Cable X 1
- IO Shield
- COM Cable X 1
- VGA Cable X 1
- Screw X 2
- Motherboard X 1

## 2. Hardware Configuration

---


## 2.1 Product Overview



## 2.2 Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board’s jumpers and connectors.

### Jumpers

Label	Function	Note
<b>JS1/JS2</b>	mSATA/Mini PCIe function Jumper	3 x 1 header, pitch 2.00 mm
<b>JBAT</b>	Clear CMOS	3 x 1 header, pitch 2.00 mm
<b>JME</b>	ME update	2 x 1 header, pitch 2.00 mm
<b>JC11/31/41/51/61</b>	Serial port 1/3/4/5/6 – Normal, 5V, 12V PIN 9 selector	3 x 2 header, pitch 2.00 mm
<b>JRS_1</b>	Serial port 2 in RS-422-485 mode	3 x 1 header, pitch 2.00 mm
<b>JRS_2</b>	Serial port 10 in RS-422-485 mode	3 x 1 header, pitch 2.00 mm
<b>JKB_MS</b>	PS/2 keyboard & mouse connector	5 x 2 header, pitch 2.54 mm
<b>JKB</b>	Keyboard power select jumper	3 x 1 header, pitch 2.00 mm
<b>JDIMM</b>	DDR3L using	2 x 1 header, pitch 2.00 mm

## EMX-B75 Quick Installation Guide


<b>Connectors</b>		
<b>Label</b>	<b>Function</b>	<b>Note</b>
<b>ATXPWR1</b>	ATX Power Input Connector	10 x 2 header, pitch 4.20 mm
<b>PWR12V</b>	Power connector	2 x 2 wafer, pitch 4.20 mm
<b>FPANEL</b>	Front Panel Switches	8 x 2 header, pitch 2.54 mm
<b>JSPDIF1</b>	Sony/Philips Digital Interface	3 x 1 header, pitch 2.54 mm
<b>JLPT</b>	Printer	2 x 13 header, pitch 2.54 mm
<b>HDMI</b>	HDMI connector	
<b>DVI-D</b>	DVI-D connector	
<b>F_AUDIO</b>	Front Panel Audio Connection Header	2 x 5 header, pitch 2.54 mm
<b>AUDIO</b>	Audio connector	
<b>COM1_3</b>	Serial port 1_3 connector	
<b>COM2/10</b>	Serial port 2/10 connector	4 x 1 header, pitch 2.54 mm
<b>COM4~9</b>	Serial port 4~9 connector	5 x 2 header, pitch 2.00 mm
<b>JGPIO1</b>	General Purpose I/O	6 x 2 header, pitch 2.54 mm
<b>USBLANA/B</b>	USB and RJ45LAN Connector A/B	
<b>PS/2</b>	Keyboard and Mouse	
<b>F_USB1/2</b>	USB Connector 1/2 - USB2.0	5 x 2 header, pitch 2.54 mm
<b>F_USB3</b>	USB Connector 3 - USB3.0	10 x 2 header, pitch 2.00 mm
<b>SATA2~6</b>	Serial ATA connector 2~6	
<b>SFAN1</b>	System Fan connector	3 x 1 wafer, pitch 2.54 mm
<b>CFAN1</b>	CPU Fan connector	4 x 1 wafer, pitch 2.54 mm
<b>JVGA</b>	VGA connector	5 x 2 header, pitch 2.54 mm
<b>MPCIE1</b>	Mini-PCIe	
<b>DIMM1</b>	DDR3 SODIMM connector1	
<b>DIMM2</b>	DDR3 SODIMM connector2	




EMX-B75 Quick Installation Guide

2.3 Setting Jumpers & Connectors

2.3.1 mSATA/Mini PCIe function Jumper (JS1/JS2)




\* Default




Pin	Pin	Define
1-3	2-4	M-SATA
3-5	4-6	MINIPCI <sup>E</sup>

2.3.2 Clear CMOS (JBAT)




\* Default



Pin	Define
1-2	Normal
2-3	Clear


EMX-B75 Quick Installation Guide

2.3.3 ME update (JME)




\* Default


Refresh the ME\*



Can't refresh the ME




2.3.4 Serial port 1/3/4/5/6 – Normal, 5V, 12V PIN 9 selector (JC11/31/41/51/61)




\* Default


Normal\*



5V




12V



PIN	Define
1-2	Normal
3-4	5V
5-6	12V


EMX-B75 Quick Installation Guide

2.3.5 Serial port 2 in RS-422-485 mode (JRS\_1)




\* Default

RS422\*




RS485



Pin	Define
1-2	RS422
2-3	RS485

2.3.6 Serial port 10 in RS-422-485 mode (JRS\_2)




\* Default

RS422\*




RS485




Pin	Define
1-2	RS422
2-3	RS485

EMX-B75 Quick Installation Guide


2.3.7 PS/2 keyboard & mouse connector (JKB\_MS)




KBCLK




KBDATA



MSCLK




MSDATA



PIN	Define	PIN	Define
1	VCC5V	2	GND
3	KBCLK-	4	KBDATA-
5	KBCLK+	6	KBDATA+
7	MSCLK-	8	MSDATA-
9	MSCLK+	10	MSDATA+


EMX-B75 Quick Installation Guide

2.3.8 Keyboard power select jumper (JKB)




\* Default

5V\*




5VSB




Pin	Define
1-2	5V
2-3	5VSB

2.3.9 DDR3L using (JDIMM)




\* Default

DDR3\*





DDR3L



Pin	Define
Open	DDR3L
Close	DDR3



EMX-B75 Quick Installation Guide

2.3.10 General Purpose I/O (JGPIO1)



Signal	PIN	PIN	Signal
+5V	1	2	+12V
GPIO	3	4	GPIO
GPIO	5	6	GPIO
GPIO	7	8	GPIO
GPIO	9	10	GPIO
GND	11	12	GND



2.3.11 VGA connector (JVGA1)



Signal	PIN	PIN	Signal
GND	1	2	R
GND	3	4	G
GND	5	6	B
HSYNC	7	8	VSYNC
DDC_DATA	9	10	DDC_CLK

EMX-B75 Quick Installation Guide

2.3.12 Serial port 4~9 connector (COM4~9)





Signal	PIN	PIN	Signal
DCD	1	2	RXD
TXD	3	4	RTD
GND	5	6	DSR
RTS	7	8	CTS
Normal	9		

Note:

Serial Port Function	Serial Port number
RS 232 with 5V/12V	COM1, COM3~COM6
RS 232 without voltage	COM7, COM8, COM9

2.3.13 Serial port 2/10 connector (COM2/10)





PIN	Signal
1	RS485_TX-
2	RS485_TX+
3	RS422_RX-
4	RS422_RX+

Note:

Serial Port Function	Serial Port number
RS 422/485	COM2 , COM10



EMX-B75 Quick Installation Guide

2.3.14      System Fan connector (SFAN1)



PIN	Signal
1	RPM
2	+12V
3	Ground

2.3.15      CPU Fan connector (CFAN1)





PIN	Signal
1	Ground
2	+12V
3	RPM
4	Control





EMX-B75 Quick Installation Guide

2.3.16 Printer (JLPT)



Signal	PIN	PIN	Signal
STB	1	2	AFD
PD0	3	4	ERR
PD1	5	6	INIT
PD2	7	8	SLIN
PD3	9	10	GND
PD4	11	12	GND
PD5	13	14	GND
PD6	15	16	GND
PD7	17	18	GND
ACK	19	20	GND
BUSY	21	22	GND
PE	23	24	GND
SLCT	25		


2.3.17 USB Connector 1/2 - USB2.0 (FUSB1/2)



Signal	PIN	PIN	Signal
VCC	1	2	VCC
Data_0-	3	4	Data_1-
DATA_0+	5	6	DATA_1+
GND	7	8	GND
		10	GND



EMX-B75 Quick Installation Guide

2.3.18 USB Connector 3 - USB3.0 (F\_USB3)



Signal	PIN	PIN	Signal
		1	VCC
VCC	19	2	SSRX-
SSRX-	18	3	SSRX+
SSRX+	17	4	GND
GND	16	5	SSTX-
SSTX-	15	6	SSTX+
SSTX+	14	7	GND
GND	13	8	D-
D-	12	9	D+
D+	11	10	ID



2.3.19 Front Panel Switches (FPANEL)



Signal	PIN	PIN	Signal
5VSB	1	2	+HD_LED
+P_LED	3	4	-HD_LED
-P_LED	5	6	PS_ON
+SPEAK	7	8	-PS_ON
NC	9	10	RESET
NC	11	12	-RESET
-SPEAK	13	14	+SLPLED
		16	-SLPLED



EMX-B75 Quick Installation Guide

2.3.20 Sony/Philips Digital Interface (JSPDIF1)



PIN	Signal
1	VCC5V
2	OUT
3	GND


2.3.21 Power connector (PWR12V)



Signal	PIN	PIN	Signal
+12V	4	3	+12V
GND	2	1	GND



EMX-B75 Quick Installation Guide

2.3.22 ATX Power Input Connector (ATXPWR1)



Signal	PIN	PIN	Signal
+12V	10	20	+5V
+5VSB	9	19	+5V
PWR_OK	8	18	-5V
GND	7	17	GND
+5V	6	16	GND
GND	5	15	GND
+5V	4	14	PS-ON
GND	3	13	GND
+3.3V	2	12	-12V
+3.3V	1	11	+3.3V

2.3.23 Front Panel Audio Connection Header (F\_AUDIO)



Signal	PIN	PIN	Signal
FRONT_MIC	1	2	GND
VREF_OUT	3	4	5V
FRONT_OUT_R	5	6	AUD_RET_R
GND	7		
FRONT_OUT_L	9	10	AUD_RET_L

