

# ERX-Q77

Intel® Q77 with Core™ i7/ i5 /i3 Micro-ATX Motherboard

## Quick Installation Guide



1<sup>st</sup> Ed – 27 November 2012

## FCC Statement



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

## Copyright Notice

Copyright © 2012 Avalue Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

## Trademark Acknowledgement

Brand and product names are trademarks or registered trademarks of their respective owners.

## Disclaimer

Avalue Technology Inc. reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. Avalue Technology assumes no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright, or masks work rights to these products, and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. Avalue Technology Inc. makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

## Life Support Policy

Avalue Technology's PRODUCTS ARE NOT FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE PRIOR WRITTEN APPROVAL OF Avalue Technology Inc.

As used herein:

1. Life support devices or systems are devices or systems which, (a) are intended for surgical implant into body, or (b) support or sustain life and whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in significant injury to the user.
2. A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness.

## A Message to the Customer

### *Avalue Customer Services*

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

### *Technical Support*

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at:

<http://www.avalue.com.tw/>

If you still cannot find the answer, gather all the information or questions that apply to your problem, and with the product close at hand, call your dealer. Our dealers are well trained

## **ERX-Q77**

and ready to give you the support you need to get the most from your Avalue's products. In fact, most problems reported are minor and are able to be easily solved over the phone. In addition, free technical support is available from Avalue's engineers every business day. We are always ready to give advice on application requirements or specific information on the installation and operation of any of our products. Please do not hesitate to call or e-mail US.

### **Headquarters and Branch**

#### **Avalue Technology Inc.**

7F, 228, Lian-cheng Road, Chung Ho City, Taipei,  
Taiwan

Tel: +886-2-8226-2345

Fax : +886-2-8226-2777

Information : [sales@avalue.com.tw](mailto:sales@avalue.com.tw)

Service: [service@avalue.com.tw](mailto:service@avalue.com.tw)

### **Avalue USA**

#### **Avalue Technology Inc.**

9 Timber Lane, Marlboro, NJ 07746-1443

Tel : (732) 414-6500

Fax : (732) 414-6501

Information : [sales@avalue-usa.com](mailto:sales@avalue-usa.com)

Service : [support@avalue-usa.com](mailto:support@avalue-usa.com)

### **BCM Advanced Research**

#### **BCM Advanced Research an Avalue Company**

7 Marconi, Irvine, CA92618

Tel: +1-949-470-1888

Fax: +1-949-470-0971

Information: [BCMSales@bcmcom.com](mailto:BCMSales@bcmcom.com)

Web: [www.bcmcom.com](http://www.bcmcom.com)

### **Avalue Europe**

#### **Avalue Europe A/S**

Moelledalen 22C, 3140

Aalsgaarde, Denmark

Tel: +45-7025-0310

Fax: +45-4975-5026

Information: [sales.europe@avalue.com.tw](mailto:sales.europe@avalue.com.tw)

Service: [service.europe@avalue.com.tw](mailto:service.europe@avalue.com.tw)

### **Avalue China**

#### **Avalue Technology Inc.**

Room 805, Building 9, No.99 Tianzhou Rd.,  
Caohejing Development Area,

Xuhui District, Shanghai

Tel: +86-21-5169-3609

Fax: +86-21-5445-3266

Information: [sales.china@avalue.com.cn](mailto:sales.china@avalue.com.cn)

Service: [service@avalue.com.tw](mailto:service@avalue.com.tw)

### **Avalue Japan**

#### **Avalue Technology Inc.**

3F Ishiyama-Bldg, 1-6-1 Taito,

Taito-ku, Tokyo 110-0016 Japan

Tel : +81-3-5807-2321

Fax : +81-3-5807-2322

Information : [sales.japan@avalue.com.tw](mailto:sales.japan@avalue.com.tw)

Service : [service@avalue.com.tw](mailto:service@avalue.com.tw)

# 1. Getting Started

## 1.1 Safety Precautions

### Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

### Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

## 1.2 Packing List

Before you begin installing your single board, please make sure that the following parts have been shipped.

- 1 x ERX-Q77 Micro-ATX Main board
- 1 x CD-ROM contains OS drivers
- 1 x COM cable
- 2 x SATA cable (2 in 1 package)
- 1 x I/O Shield



---


If any of the above items is damaged or missing, contact your retailer.

---

## 2. Hardware Configuration

---


## 2.1 Product Overview



## 2.2 Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board's jumpers and connectors.

Slots & socket			
Label	Function	Note	
LGA1155	LGA1155 socket		
DIMMA1	240-pin DDR3 DIMM Slot A1		
DIMMA2	240-pin DDR3 DIMM Slot A2		
DIMMB1	240-pin DDR3 DIMM Slot B1		
DIMMB2	240-pin DDR3 DIMM Slot B2		
PCIEX16	PCI-e x16 Slot		
PCI1~3	PCI Slot		

Jumpers			
Label	Function	Note	
CLCMOS1	Clear CMOS	3 x 1 header, pitch 2.54mm	
PSOEN1	AT/ATX Mode Select	3 x 1 header, pitch 2.54mm	



**Quick Installation Guide**





















CN2	COM1 RS232/422/485 SETTING	9 x 2 header, pitch 2.00mm
CN4	COM5 RS232/485 SETTING	5 x 2 header, pitch 2.00mm
JCOMPWR1	COM3 POWER SETTING	3 x 2 header, pitch 2.00mm
JBKLVOL1	LVDS Backlight power selection	3 x 1 header, pitch 2.00mm
JBKL2	LVDS Backlight control mode	3 x 1 header, pitch 2.00mm

Rear Panel Connector		
Label	Function	Note
KBMS	PS/2 Keyboard and Mouse	6-pin Mini-Din
COM1	COM1 Connector	D-sub 9-pin, male
COM2	COM2 Connector	D-sub 9-pin, male
CN3	VGA Port	D-sub 15-pin, female
HDMI1	HDMI Port	HDMI 1.3 19-pin
LAN1_USB12	RJ-45 Ethernet Connector x 1 USB 3.0 Connector x 2	
LAN2_USB34	RJ-45 Ethernet Connector x 1 USB 3.0 Connector x 2	
AUDIO	Audio Line-In , Line-Out , Mic.-In	5.1 Channel Audio I/O (3 jacks)




## 2.2.1 Internal Connectors

Internal Connector		
Label	Function	Note
CPU_FAN	CPU Fan Connector	4 x 1 wafer, pitch 2.54mm
SYS_FAN	System Fan Connector	4 x 1 wafer, pitch 2.54mm
CHA_FAN	Chassis Fan Connector	4 x 1 wafer, pitch 2.54mm
F_PANEL	Intel Front Panel connector	5 x 2 header, pitch 2.54mm
EATXPWR1	ATX power connectors	12 x 2 wafer
ATX12V1	12V ATX power connectors	2 x 2 wafer
COM3 ~ 5	Serial Port Connector	5 x 2 header, pitch 2.54mm
DIO1	Digital I/O Connector	6 x 2 header, pitch 2.54mm
FPAUD1	Audio Mic.-In & Line-Out Connector	5 x 2 header, pitch 2.54mm
SPDIF_OUT	Digital Audio connector	4 x 1 header, pitch 2.54mm
JAMP1	Amplifier Connector	4 x 1 header, pitch 2.54mm
SATA1 ~ 6	SATA Data Connector * 6	7P Male connector
USB5~10	USB Connector * 6	5 x 2 header, pitch 2.54mm
LVDS1	LVDS Connector	20 x 2 wafer
JBKL1	LVDS Inverter Power Connector	5 x 1 wafer, pitch 2.00mm
LPT1	Print Port Connector	13 x 2 wafer, pitch 2.00mm










## 2.3 Setting Jumpers & Connectors







Jumpers			
Label	Function	Note	
CLCMOS1	Clear CMOS 	Normal 	Clear CMOS 
PSON1	AT/ATX Mode 	ATX MODE 	AT MODE 
CN2	COM1 RS232/422/485 SETTING 	RS232 	
		RS422 	
		RS485 	
CN4	COM5 RS232/485 SETTING 	RS232 	RS485 
JCOMPWR1	COM3 POWER SETTING 	Ring 	+12V 
		+5V 	
JBKLVOL1	LVDS Backlight power selection 	+3.3V 	+5V 

## Jumpers

Label	Function	Note	
JBKL2	LVDS Backlight control mode	PWM (Default)	Linear
			

## Connectors

Label	Function	Note	
CPU_FAN	CPU Fan Connector		4. FAN_PWM1_C 3. FANCPUDEC1 2. +V12 1. GND
SYS_FAN	System Fan Connector		4. FAN_PWM2_C 3. FANCPUDEC2 2. +V12 1. GND
CHA_FAN	Chassis Fan Connector		4. FAN_PWM3_C 3. FANCPUDEC3 2. +V12 1. GND
COM3	Serial Port Connector		1. COM_C-DCD3# 3. COM_C-TXD3 5. GND 7. COM_C-RTS3# 9. RI3xPOWERxJMP 2. COM_C-RXD3 4. COM_C-DTR3# 6. COM_C-DSR3# 8. COM_C-CTS3#
COM4	Serial Port Connector		1. COM_C-DCD4# 3. COM_C-TXD4 5. GND 7. COM_C-RTS4# 9. COM_C-RI4# 2. COM_C-RXD4 4. COM_C-DTR4# 6. COM_C-DSR4# 8. COM_C-CTS4#
COM5	Serial Port Connector		1. COM_C-DCD5# 3. COM_C-TXD5 5. GND 7. COM_C-RTS5# 9. COM_C-RI5# 2. COM_C-RXD5 4. COM_C-DTR5# 6. COM_C-DSR5# 8. COM_C-CTS5#
DIO1	Digital I/O Connector		1. DIO_GP0 3. DIO_GP1 5. DIO_GP2 7. DIO_GP3 9. SMB_CLK_RESUME 11. GND 2. DIO_GP4 4. DIO_GP5 6. DIO_GP6 8. DIO_GP7 10. SMB_DATA_RESUME 12. +V5_DUAL
F_PANEL	Intel Front Panel connector		1. HDD_LED+ 3. SATA_LED# 5. GND 7. SRST# 9. NC 2. +V5_DUAL 4. SUPLED1 6. PANSWIN# 8. GND
FPAUD1	Audio Mic.-In & Line-Out Connector		1. MIC2L 3. MIC2R 5. LINE2R 7. FRONT-IO-SENSE_C 9. LINE2L 2. GND 4. PCH_GPIO34 6. MIC2-JD 8. NC 10. LINE2-JD

Connectors				
Label	Function		Note	
SPDIF_O	Digital Audio connector		1. +V5 2. NC 3. SPDIF-OUT 4. GND	
JAMP1	Amplifier Connector		1. AMP_L- 2. AMP_L+ 3. AMP_R- 4. AMP_R+	
LVDS1	LVDS Connector		2. VDD_+5V 4. VDD_+5V 6. DDC_DATA 8. GND 10. LVDS_A0+ 12. LVDS_A0- 14. GND 16. LVDS_A2+ 18. LVDS_A2- 20. GND 22. LVDS_B0+ 24. LVDS_B0- 26. GND 28. LVDS_B2+ 30. LVDS_B2- 32. GND 34. LVDS_A_CLK+ 36. LVDS_A_CLK- 38. GND 40. VDD_+12V	1. VDD_+3V 3. VDD_+3V 5. DDC_CLK 7. GND 9. LVDS_A1+ 11. LVDS_A1- 13. GND 15. LVDS_A3+ 17. LVDS_A3- 19. GND 21. LVDS_B1+ 23. LVDS_B1- 25. GND 27. LVDS_B3+ 29. LVDS_B3- 31. GND 33. LVDS_B_CLK+ 35. LVDS_B_CLK- 37. GND 39. VDD_+12V
JBKL1	LVDS Inverter Power Connector		1. +12V 2. GND 3. BL_EN 4. Backlight 5. +5V	
LPT1	Print Port Connector		1. LPT_STB# 3. LPT_PD0 5. LPT_PD1 7. LPT_PD2 9. LPT_PD3 11. LPT_PD4 13. LPT_PD5 15. LPT_PD6 17. LPT_PD7 19. LPT_ACK# 21. LPT_BUSY 23. LPT_PE 25. LPT_SLCT	2. LPT_AFD# 4. LPT_ERR# 6. LPT_INIT# 8. LPT_SLIN# 10. GND 12. GND 14. GND 16. GND 18. GND 20. GND 22. GND 24. GND 26. NC
USB56 USB78 USB910	USB 2.0 Connector		1. USB +5V 3. USB- 5. USB+ 7. GND	2. USB +5V 4. USB- 6. USB+ 8. GND 10. NC

