Subject : EMX-965GME setting LVDS+DVI display in Windows XP Professional.

FAQ Document No: H10012	Date: 2010/11/09
Model Name. EMX-965GME	Rev. A1

Category: ☐General ■H/W ☐S/W ☐Others, __Display__

Purpose: Dual Display LVDS+DVI display function.

Please follow procedure step by step as below:

**1. Firstly, please update AMI BIOS: 965GA315.T06.FD to EMX-965GME**

2. Reboot system and loading optimized defaults in CMOS setup utility.

3. Shut down the system and setup LVDS and DVI device in EMX-965GME

4. Into Windows XP, Install IEGD driver: IEGD_10_0_Windows

   After finished, you can see graphic card list in Device Manager:

5. Start setting Display config:


Example:

Test environment:

1. **OS: Windows XP SP3**
2. **LVDS: AUO G150XG03 V1 1024x768 18bit**
3. **DVI:　CHIMEI 22GH DVI-D**
4. **Primary Display: DVI, secondary display：LVDS**

　　A. DVI+LVDS extend mode:

Avalue Technology Inc.　　　　　　　　　　　　　　　　　　　7F, 228, Lian-Cheng Road, Chung Ho City, Taipei, Taiwan R.O.C.

www.avalue.com.tw	Avalue Europe	Avalue USA	BCM Advanced Research	Avalue China
sales@avalue.com.tw	sales.europe@avalue.com.tw	sales@avalue-usa.com	BCMSales@bcmcom.com	sales.china@avalue.com.cn
Tel:+886-2-82262345	Tel: +45-7025-0310	Tel: +1-732-578-0200	Tel: +1-949-470-1888	Tel: +86-21-5426-3399
Fax:+886-2-82262777	Fax: +45-4975-5026	Fax: +1-732-578-0250	Fax: +1-949-470-0971	Fax: +86-21-6495-0370

www.avalue.com.tw

B. DVI+LVDS Clone mode

Avalue Technology Inc.   7F, 228, Lian-Cheng Road, Chung Ho City, Taipei, Taiwan R.O.C.

www.avalue.com.tw	Avalue Europe	Avalue USA	BCM Advanced Research	Avalue China
sales@avalue.com.tw	sales.europe@avalue.com.tw	sales@avalue-usa.com	BCMSales@bcmcom.com	sales.china@avalue.com.cn
Tel:+886-2-82262345	Tel: +45-7025-0310	Tel: +1-732-578-0200	Tel: +1-949-470-1888	Tel: +86-21-5426-3399
Fax:+886-2-82262777	Fax: +45-4975-5026	Fax: +1-732-578-0250	Fax: +1-949-470-0971	Fax: +86-21-6495-0370

www.avalue.com.tw

Remark : 1.The different LVDS resolution there are modify VGA BIOS.
2.Change Primary display need modify Intel IEGD driver.

--End