

EPC-CDV

**Fanless Intel® Atom™ D2550 Tiny Box PC
with Intel® NM10 Express Chipset**

Quick Reference Guide

1st Ed – 27 July 2012

Copyright Notice

Copyright © 2012 Avalue Technology Inc., ALL RIGHTS RESERVED.

Content

- 1. Getting Started3**
 - 1.1 Safety Precautions3
 - 1.2 Packing List3
 - 1.3 System Specifications4
 - 1.4 System Overview.....6
 - 1.4.1 Front & Rear View 6
 - 1.5 System Dimensions.....7
 - 1.5.1 Top/ Front & Side (with rubber foot) 7
 - 1.5.2 Top/ Front & Side (with wallmount)..... 8
- 2. Hardware Configuration.....9**
 - 2.1 EPC-CDV connector list10
 - 2.2 EPC-CDV connector mapping.....11
 - 2.2.1 External Serial Port 1 connector (COM1) 11
 - 2.2.2 External Serial Port 2 connector (COM2/DVI) 11
 - 2.2.3 VGA connector (VGA)..... 12
 - 2.3 Installing Aluminum Stand (EPC-CDV).....13
 - 2.4 Installing Hard Disk & Memory (EPC-CDV).....14
 - 2.5 Installing Mounting Bracket (Optional).....16

1. Getting Started

1.1 Safety Precautions

Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

1.2 Packing List

- 1 x EPC-CDV (with ECM-CDV)
- 1 x Quick Reference Guide
- 1 x DVD-ROM contains the followings:
 - User's Manual (this manual in PDF file)
 - Ethernet driver and utilities
 - VGA drivers and utilities
 - Audio drivers and utilities
 - Chipset drivers and utilities
- Other major components include the followings:
 - Screw kit for 2.5" HDD/SSD and stand fixing
 - AC to DC Adapter
 - Power Cord
 - Aluminum Stand



If any of the above items is damaged or missing, contact your retailer.

1.3 System Specifications


System	
Board	ECM-CDV
CPU	Onboard Intel® Atom™ D2550 1.86GHz CPU
BIOS	AMI 16Mbit SPI BIOS
System Chipset	Intel® NM10 Express Chipset
I/O Chip	Nuvoton W83627DHG-P
System Memory	One 204-pin DDR3 SODIMM Socket Up to 4GB DDR3 800/ 1066 SDRAM
SSD	One CompactFlash Type I/II Socket
Hard Disk	1 x 2.5" SATA HDD/ SSD
Watchdog Timer	Reset: 1sec. ~ 65535sec./min. and 1sec. or 1min./step
H/W Status Monitor	Monitoring System Temperature, Voltage with Auto Throttling Control
External I/O	
COM Port	1 x RS-232, 1 x RS-232/ 422/ 485 (Setting by Jumper & BIOS)
LAN Port	2 x RJ-45
Antenna	2 Knockouts for Antenna Mounting (Options to Add WiFi & 3G)
VGA	1 x VGA
Audio Port	Mic-in, Line-in, Line-out
USB Port	5 x USB 2.0 (Rear 4; Front 1)
Expansions	1 x Mini-PCIe Socket (mSATA supported)
Display	
Chipset	Intel® Cedarview Integrated Graphics
Resolution	CRT Mode: 1920 x 1200 @ 60Hz
Audio	
AC97 Codec	Realtek ALC892 Supports 5.1-CH Audio
Audio Interface	Mic-in, Line-in, Line-out
Ethernet	
LAN Chip	2 x Intel® 82574L Gigabit Ethernet
Ethernet Interface	10/ 100/ 1000 Base-Tx Gigabit Ethernet Compatible

Environment & Mechanical	
Power Requirement	+12 ~ +26Vdc (+12V/ 5A Lockable DC Plug Adapter is an Accessory to This System)
ACPI	Single Power ATX Support S0, S3, S4, S5 ACPI 3.0 Compliant
Power Type	AT/ ATX (ATX is The Default Setting)
Operating Temperature	0 ~ 50°C (32 ~ 122°F) (w/ CF & SSD), Ambient w/ Air Flow 0 ~ 40°C (32 ~ 104°F) (w/ HDD), Ambient w/ Air Flow
Storage Temperature	-40 ~ 75°C (-40 ~ 167°F)
Relative Humidity	0% ~ 90% Relative Humidity, Non-condensing
Dimension (W x D x H)	7" x 4.4" x 2.0" (178mm x 112mm x 50mm)
Weight	2.7lbs (1.2Kgs)
Mounting	VESA Compliance


1.4 System Overview

1.4.1 Front & Rear View

Front View




Rear View



1.5 System Dimensions


1.5.1 Top/ Front & Side (with rubber foot)



(Unit: mm)

EPC-CDV

1.5.2 Top/ Front & Side (with wallmount)



(Unit: mm)

2. Hardware Configuration

Please refer to ECM- CDV Quick Installation Guide or User's Manual for advanced information.



Note: If you need more information, please visit our website:

<http://www.avalue.com.tw>



2.1 EPC-CDV connector list

Connectors

Label	Function	Note
COM1	Serial port 1 connector	
COM2/DVI	Serial port 2 connector	
Compact Flash	Compact Flash card connector	Type I/II x 1
12V DC-IN	DC power-in connector	
LAN1	RJ-45 Ethernet 1	
LAN2	RJ-45 Ethernet 2	
LINE IN	Line-in audio jack	
LINE OUT	Line-out audio jack	
MIC IN	Mic-in audio jack	
HDD	HDD indicator	
USB1~5	USB 1~5 connector	
PWR	System power indicator	
VGA	VGA connector	D-sub 15-pin, female
HDMI	HDMI connector	



2.2 EPC-CDV connector mapping

2.2.1 External Serial Port 1 connector (COM1)





Signal	PIN	PIN	Signal
DCDA#	1	2	RxDA
TxDA	3	4	DTRA#
GND	5	6	DSRA#
RTSA#	7	8	CTSA#
RIA#	9	10	NC

2.2.2 External Serial Port 2 connector (COM2/DVI)




Signal	PIN	PIN	Signal
DCDB#	1	2	RxDB
TxDB	3	4	DTRB#
GND	5	6	DSRB#
RTSB#	7	8	CTSB#
RIB#	9	10	NC

2.2.3 VGA connector (VGA)




PIN	Signal	PIN	Signal	PIN	Signal
1	R	6	GND	11	NC
2	G	7	GND	12	DATA
3	B	8	GND	13	HSYNC
4	NC	9	+5V	14	VSYNC
5	GND	10	GND	15	CLK

2.3 Installing Aluminum Stand (EPC-CDV)



Step1.


Attach stand to your system by means of two screws.



Step2.


Stand installation completed.

2.4 Installing Hard Disk & Memory (EPC-CDV)




Step1.

Remove the 4 screws from VGA and COM before removing back cover.



Step2.

Remove the 8 screws to disassemble your system front & back cover.




Step3. 1

For HDD installation, please remove 4 screws to detach top cover, HDD enclosure from board & system assembly.

Step3. 2

Fix HDD using the 3 screws in the Accessory Kit.




Step4.1

Properly install the memory module and press until properly seated.

Step4.2

Re-assemble your system back through previous steps to complete the installation.

2.5 Installing Mounting Bracket (Optional)



Step 1. Fasten 4 screws on both sides of EPC Embedded System.

