

Application Note

Subject :CH7511B eDP/DP to LVDS monitor controller Firmware updating simple guide.

FAQ Document No: S12005

Model Name. ECM-CDV'EBM-CDV

Rev. A1

Category: General H/W S/W Others,

Purpose:


Simple guide for Updating new Firmware CH7511B with new Panel DTD table supported.

1. Preparing below folder files into windows folder from CH7511_UFU_PKG.zip.





- Step3_Firmware
- Prepare working Environment OS: WINDOWS XP/ WINDOWS 7 32bit On CDV chipset platform.
- 3. Install SMBUS driver for your OS by click "install" (PS: while OS restart, this SMBUS driver will be removed automatically) from subfolder name "Step1_SMBUSDRVsetupX86"




Avalue Technology Inc.


7F, 228, Lian-Cheng Road, Chung Ho City, Taipei, Taiwan R.O.C.



4. Launch Chrontel CH7511B Image utility by click "CH7511B-Utility-V1.01.16" from subfolder "Step2_utility".




Select section of "CH7511B Image Copy" and click "Import"






5. Find the new Firmware from subfolder "Step3_Firmware". Click it and open.



6. Change the CH7511B interface by click "Options"




Avalue Technology Inc.


7F, 228, Lian-Cheng Road, Chung Ho City, Taipei, Taiwan R.O.C.




Select SMBUS and click OK



7. Click "Flash" to start Firmware updating.









After pop up screen "Flash Finished!" appeared. Please reboot your Board.

Select correct Panel ID item from BIOS, boot CDV board into windows, you will get correct displayed on your Panel



9. Done!